



# AFP-3030/NCA-2 Emergency Operation Sheet



- A. Zone Address and Zone Name
- B. Point Name
- C. Time of Alarm Event
- D. Event Counter
- E. Alarm Counter
- F. Point Address
- G. Current Time and Date



## Disable a Zone

1. Enter the Main Menu by pressing the **ESC/MENU** key, and select **DISABLE/ENABLE** using the soft key. This will bring up the Point Select Screen.
2. Press **POINT SELECT** to cycle through the types of points that can be disabled, until "(ZONE)" is shown.
3. Enter the address of the zone to be disabled using the keyboard, or select the zone using the **NEXT POINT** and **PREVIOUS POINT** soft keys, then press **ACCEPT**.
4. Press the **DISABLE** soft key at the next screen to disable the selected zone.
5. At the confirmation screen, select **YES** to disable the zone, or **NO** to return to the previous screen.
6. To re-enable the zone, repeat Steps 1 to 3, and select **ENABLE**.