



NOTIFIER[®]
by Honeywell

9 Columbia Way
Baulkham Hills, NSW 2153
PH 02-9894-1444 • FAX 02-9894-4193
www.notifier.com.au

FG-65-012 –Replacement 3-Volt Battery Installation Sheet - Released

23/10/2013 Rev: A

DOC-03-072 ECN13-0085

1 Product Overview

The 3-Volt battery powers the system clock. The 3-Volt battery is located on the CPU board. The system clock will only run on the 3-Volt battery if both the 240AC and the battery supplies fail.

2 Installation



WARNING: Remove all power sources to the panel before installation. Leave the external and main power OFF until installation is complete.

To install the 3-Volt Battery

1. Gently lift up the battery clip and slide the existing battery out from the battery holder.
2. Gently lift up the battery clip and slide the replacement battery in to the battery holder.



CAUTION: Dispose of any used batteries according to the manufacturer's instructions.

3 Components

Part No.	Description	Qty
DOC-03-072	Replacement 3-Volt Battery Install Sheet	1
GEN-00-005	Lithium Coin Cell Battery	1

Table 1: Components